

Mounting and wiring instruction manual

4 points Analog I/O Module **QAM1-4** No. QAM11E3 2025.04

Preface

Thank you for purchasing our 4 points Analog I/O Module [QAM1-4]. This manual contains instructions for the mounting and wiring when operating the 4 points Analog I/O Module [QAM1-4]. To prevent accidents arising from the misuse of this instrument, please ensure the operator receives this manual.

For details on how to use it, refer to the instruction manual (detailed version).

Please access our website from the following URL or QR code to download the instruction manual (detailed version).
https://shinko-technos.co.jp/e/download/d_manual_download.htm#Q



Notes

- This instrument should be used in accordance with the specifications described in the manual. If it is not used according to the specifications, it may malfunction or cause a fire.
- Be sure to follow the warnings, cautions and notices. If they are not observed, serious injury or malfunction may occur.
- The contents of this instruction manual are subject to change without notice.
- Care has been taken to ensure that the contents of this instruction manual are correct, but if there are any doubts, mistakes or questions, please inform our sales department.
- This instrument is designed to be installed on a DIN rail within a control panel. If it is not, measures must be taken to ensure that the operator does not touch power terminals or other high voltage sections.
- Any unauthorized transfer or copying of this document, in part or in whole, is prohibited.
- Shinko Technos Co., Ltd. is not liable for any damage or secondary damage(s) incurred as a result of using this product, including any indirect damage.

SAFETY PRECAUTIONS

(Be sure to read these precautions before using our products.)

The safety precautions are classified into categories: "Warning" and "Caution". Depending on circumstances, procedures indicated by ⚠ Caution may result in serious consequences, so be sure to follow the directions for usage.



Procedures which may lead to dangerous conditions and cause death or serious injury, if not carried out properly.



Caution

Procedures which may lead to dangerous conditions and cause superficial to medium injury or physical damage or may degrade or damage the product, if not carried out properly.



Warning

- To prevent an electrical shock or fire, only Shinko or qualified service personnel may handle the inner assembly.
- To prevent an electrical shock, fire, or damage to instrument, parts replacement may only be undertaken by Shinko or qualified service personnel.



Safety Precautions

- To ensure safe and correct use, thoroughly read and understand this manual before using this instrument.
- This instrument is intended to be used for industrial machinery, machine tools and measuring equipment. Verify correct usage after purpose-of-use consultation with our agency or main office. (Never use this instrument for medical purposes with which human lives are involved.)
- Please contact us for periodic maintenance (for a fee).
- This instrument must be used under the conditions and environment described in this manual. Shinko Technos Co., Ltd. does not accept liability for any injury, loss of life or damage occurring due to the instrument being used under conditions not otherwise stated in this manual.



Caution with Respect to Export Trade Control Ordinance

To avoid this instrument from being used as a component in, or as being utilized in the manufacture of weapons of mass destruction (i.e. military applications, military equipment, etc.), please investigate the end users and the final use of this instrument. In the case of resale, ensure that this instrument is not illegally exported.

Precautions for Use

Installation Precautions



Caution

This instrument is intended to be used under the following environmental conditions (IEC61010-1):

- Overvoltage Category II, Pollution degree 2

Ensure the mounting location corresponds to the following conditions:

- A minimum of dust, and an absence of corrosive gases
- No flammable, explosive gases
- No mechanical vibrations or shocks
- No exposure to direct sunlight, an ambient temperature of -10 to 50°C (14°F to 122°F) that does not change rapidly, and no icing
- An ambient non-condensing humidity of 35 to 85 %RH
- No large capacity electromagnetic switches or cables through which large current is flowing
- No water, oil or chemicals or the vapors of these substances can come into direct contact with the unit.
- When installing this unit within a control panel, please note that ambient temperature of this unit – not the ambient temperature of the control panel – must not exceed 50°C (122°F). Otherwise the life of electronic components (especially electrolytic capacitor) may be shortened.
- Avoid setting this instrument directly on or near flammable material even though the case of this instrument is made of flame-resistant resin.

Wiring Precautions



Caution

- Do not leave bits of wire in the instrument, because they could cause a fire and malfunction.
- When wiring, use a crimping pliers and a solderless terminal with an insulation sleeve in which an M3 screw fits.

- The terminal block of this instrument has a structure that is wired from the left side. Be sure to insert the lead wire into the terminal of the instrument from the left side and tighten the terminal screw.
- Tighten the terminal screw using the specified torque. If excessive force is applied to the screw when tightening, the screw or case may be damaged.
- Do not pull or bend the lead wire with the terminal as the base point during or after wiring work. It may cause malfunction.
- This instrument does not have a built-in power switch, circuit breaker and fuse. It is necessary to install an appropriate power switch, circuit breaker and fuse near the instrument.
- When wiring the power supply (24 VDC), do not confuse the polarities.
- Do not apply a commercial power source to the sensor which is connected to the input terminal nor allow the power source to come into contact with the sensor.
- Use the thermocouple and compensation lead wire that match the sensor input specifications of the instrument.
- Use a RTD of 3-conducting wire type that meets the sensor input specifications of this instrument.
- When using a relay contact output type, externally use a relay according to the capacity of the load to protect the built-in relay contact.
- Separate the input line (thermocouple, RTD, etc.) from the power line and load line.

Operation and Maintenance Precautions



Caution

- It is recommended that auto-tuning (AT) be performed on the trial run.
- Do not touch live terminals. This may cause electrical shock or problems in operation.
- Turn the power supply to the instrument OFF when retightening the terminal or cleaning. Working on or touching the terminal with the power switched ON may result in severe injury or death due to electrical shock.
- Use a soft, dry cloth when cleaning the instrument. (Alcohol based substances may tarnish or deface the unit.)
- As the panel part is vulnerable, be careful not to put pressure on, scratch or strike it with a hard object.

CUnet is a registered trademark of StepTechnica Co., Ltd.


1. Specifications

Power supply voltage	24 V DC
Allowable voltage fluctuation	20 to 28 V DC
Power consumption	Approx. 5 W or less
Input reference accuracy (Ambient temp.: 23°C)	Thermocouple input: (Within ±0.2% of each input span) Within 0 °C (32 °F), within ±0.4% of each input span R, S input, 0 to 200 °C (32 to 392 °F): Within ±6 °C (12 °F) B input, 0 to 300 °C (32 to 572 °F): Accuracy is not guaranteed. RTD input: Within ±0.1% of each input span DC current input, DC voltage input: Within ±0.2% of each input span DC current output, DC voltage output: Within ±0.2% of each input span
Output reference accuracy (Ambient temp.: 23°C)	DC current output, DC voltage output: Within ±0.2% of each input span
Cold junction compensation accuracy	Within ±1°C at -10 to 50°C
Input sampling cycle	20 ms (*1), 50 ms (*1), 125 ms (*2) (*1): Valid only for DC current input and DC voltage input. (*2): For temperature input, fixed at 125 ms regardless of setting.
Output update cycle	20 ms
Output circuit response time	100 ms or less (excluding 0 to 90% communication cycle time)
Setting accuracy	Comply with standard accuracy
Serial communication	Reads and sets various setting values, reads PV operating status, and changes functions from an external computer. Communication line: EIA RS-485 compliant Communication method: Half-duplex communication Synchronization method: Asynchronous Communication protocol: MODBUS RTU Communication speed: 9600, 19200, 38400, 57600 bps Data bit: 8 Parity: Even, odd, no parity Stop bit: 1 or 2 Response delay: 0 to 1000 ms (factory default: 0 ms) Connection type: Multi-drop Communication method: 2-wire half-duplex Synchronization method: Bit-synchronous Error detection: CRC-16 Number of occupied slave addresses: 1 Maximum number of connected nodes: 64 nodes Communication speed: 12 Mbps (100 m), 6 Mbps (200 m), (cable length) 3 Mbps (300 m) Isolation method: Pulse transformer isolation Impedance: 100 Ω
CUnet communication	-10 to 50 °C (no condensation or freezing) 35 to 85 %RH (no condensation) RoHS directive compliant Approx. 170 g Overvoltage Category II, Pollution degree 2 (IEC61010-1) Non-volatile memory (Number of writes: 1 trillion times)

2. Overview

This instrument is a 4 points Analog I/O Module. A multi-point measurement system can be configured with the control module alone, or via a host computer or PLC. A maximum of 16 instruments can be connected via BUS, and a maximum of 64 points can be measured. One block connected to BUS is called "1 unit".

Configuration example



3. Model

QAM1-4	<input type="checkbox"/>	No option																
Power supply / communication option	0																	With power supply / upper communication function
	P																	With power supply / CUnet communication function
Wiring type	C																	With power supply / CUnet communication function
	T																	Terminal block type
I/O type (*)	-0																	Input 4 points
	-1																	Output 4 points
	-2																	I/O 4 points each
Analogue output 1																		Refer to output code table
Analogue output 2																		
Analogue output 3																		
Analogue output 4																		
Analogue input 1																		Refer to input code table
Analogue input 2																		
Analogue input 3																		
Analogue input 4																		

(*): For input-only type, output code selection is invalid.
 For output-only type, input code selection is invalid.

Output code table

Output code	Output type
A	DC current output 4 to 20 mA DC
0	DC current output 0 to 20 mA DC
V	DC voltage output 0 to 1 V DC
1	DC voltage output 0 to 5 V DC
2	DC voltage output 1 to 5 V DC
3	DC voltage output 0 to 10 V DC
N (*)	No output


(*): Output code N is valid only when I/O type 0 (Input 4 points) is selected.

Input code table


Input code	Input type	Range	
M	Thermocouple input	K	-200 to 1370 °C
		K	-200.0 to 400.0 °C
		J	-200 to 1000 °C
		R	0 to 1760 °C
		S	0 to 1760 °C
		B	0 to 1820 °C
		E	-200 to 800 °C
		T	-200.0 to 400.0 °C
		N	-200 to 1300 °C
		PL-II	0 to 1390 °C
		C(W/Re5-26)	0 to 2315 °C
		K	-328 to 2498 °F
		K	-328.0 to 752.0 °F
		J	-328 to 1832 °F
		R	32 to 3200 °F
		S	32 to 3200 °F
B	32 to 3308 °F		
E	-328 to 1472 °F		
T	-328.0 to 752.0 °F		
N	-328 to 2372 °F		
PL-II	32 to 2534 °F		
C(W/Re5-26)	32 to 4199 °F		
RTD input	Pt100	-200.0 to 850.0 °C	
	Pt100	-328.0 to 1562.0 °F	
DC voltage input	0 to 1 V DC	-2000 to 10000	
	4 to 20 mA DC (External receiving resistor)	-2000 to 10000	
DC current input	0 to 20 mA DC (External receiving resistor)	-2000 to 10000	
	4 to 20 mA DC (Built-in receiving resistor)	-2000 to 10000	
A	0 to 20 mA DC (Built-in receiving resistor)	-2000 to 10000	
	0 to 20 mA DC (Built-in receiving resistor)	-2000 to 10000	
V	0 to 5 V DC	-2000 to 10000	
	1 to 5 V DC	-2000 to 10000	
	0 to 10 V DC	-2000 to 10000	
N (*)	No input		

(*): Input code N is valid only when I/O type 1 (Output 4 points) is selected.

4. Name and Functions




Base part



Panel part

Depending on whether have the option, the panel design differs. With power supply / upper communication function, With power supply / CUnet communication function, No power supply / communication option.



Operation indicator

No.	Symbol (color)	Name	Function
①	PWR (Green)	Power indicator	When energized: Lights up During warm-up: Flashing for 3 sec. (500 ms cycle) Non-volatile IC memory error or ADC error: Flashing (500 ms cycle)
②	T/R (Yellow)	Communication indicator	During communication TX output: lights up
③	O1 (Green)	Analog output 1 indicator	Always lights off
④	O2 (Green)	Analog output 2 indicator	Always lights off
⑤	O3 (Green)	Analog output 3 indicator	Always lights off
⑥	O4 (Green)	Analog output 4 indicator	Always lights off
⑦	EVT (Red)	Event indicator	Sensor error: Flashing (250 ms cycle) Overscale/Underscale: Flashing (500 ms cycle) When powered by PC via USB bus power: Flashing (250 ms cycle)

Switch and connector

No.	Symbol	Name
⑧	ADD.	Module address setting rotary switch
⑨	USB	Console communication connector
⑩		Communication specification setting dip switch
⑪		CUnet communication specification setting dip switch

5. Communication Parameter Setting

5.1 Setting of Communication Specifications

Caution

When connecting to the communication expansion module QMC1, the communication specification selection is not required. Use it in the factory default (all OFF).

Use the communication specification setting switch on the left side of the instrument to set communication specifications.

Set the communication speed, data bit, parity and stop bit.

The factory default settings are as follows.

- Communication speed
 - With power supply / upper communication function: 57600 bps
 - With power supply / CUnet communication function: 38400 bps
- Data bit: 8 bits
- Parity: Even
- Stop bit: 1 bit

(1) Setting of communication speed

Communication specification setting dip switch		Communication speed
1	2	
OFF	OFF	57600 bps
ON	OFF	38400 bps
OFF	ON	19200 bps

ON	ON	9600 bps
----	----	----------

(2) Setting of data bit, parity and stop bit

Communication specification setting dip switch			Data bit, parity and stop bit
3	4	5	
OFF	OFF	OFF	8 bits, Even, 1 bit
ON	OFF	OFF	8 bits, Even, 2 bits
OFF	ON	OFF	8 bits, Odd, 1 bit
ON	ON	OFF	8 bits, Odd, 2 bits
OFF	OFF	ON	8 bits, None, 1 bit
ON	OFF	ON	8 bits, None, 2 bits


Dip switches No.6, No.7 and No.8 does not use. Leave it OFF.

5.2 Setting of Module Address

Caution

When using the SIF function, module addresses should be set to consecutive numbers starting from 1.
When using the MODBUS specification, any number between 0 to F (1 to 16) can be set.

The module addresses are set with the rotary switch.
Use a small flat-blade screwdriver to set the module addresses.
The value obtained by adding 1 to the value of the set rotary switch becomes the module addresses.




Module address: 0 to F (1 to 16)

Rotary switch	0	1	9	A	B	F
Module address	1	2	10	11	12	16

5.3 Setting of CUNet communication specification

The CUNet communication specifications are set by the dip switches (SW10, SW11) on the base part.
Refer to (1) in "7.2.2 Power Supply and Communication Terminal Arrangement" to remove the case.
After setting, refer to (3) in "7.2.2 Power Supply and Communication Terminal Arrangement" to mount the case.



(1) Setting of Station Address and Communication Speed (SW10)

No.	Setting item	Status	Factory default
1	Station address setting	Bit0 ON: Enable, OFF: Disable	Disable
2		Bit1 ON: Enable, OFF: Disable	Disable
3		Bit2 ON: Enable, OFF: Disable	Disable
4		Bit3 ON: Enable, OFF: Disable	Disable
5		Bit4 ON: Enable, OFF: Disable	Disable
6	Bit5 ON: Enable, OFF: Disable	Disable	
7	Communication speed setting	7: OFF 8: OFF 12 Mbps	12 Mbps
8		7: ON 8: OFF 6 Mbps 7: OFF 8: ON 3 Mbps 7: ON 8: ON Disable(12 Mbps)	

(2) Select master address and number of occupied (OWN) items (SW11)

No.	Setting item	Status	Factory default
1	Master address setting	Bit0 ON: Enable, OFF: Disable	Disable
2		Bit1 ON: Enable, OFF: Disable	Disable
3		Bit2 ON: Enable, OFF: Disable	Disable
4		Bit3 ON: Enable, OFF: Disable	Disable
5		Bit4 ON: Enable, OFF: Disable	Disable
6	Bit5 ON: Enable, OFF: Disable	Disable	
7	Number of occupied (OWN) items selection(*)	7: OFF 8: OFF 1 item	1 item
8		7: ON 8: OFF 2 items 7: OFF 8: ON 3 items 7: ON 8: ON 4 items	

(*): The following items are allocated to global memory for each module.

Number of occupied (OWN) items	QAM1	
	DI item	DO item
1	PV: 03E8-03EB	Output: 0014-0017
2	Status 1: 03F4-03F7	
3	MV: 03EC-03EF	
4		

Shaded area is invalid because there is no allocation (no area is allocated in

global memory)

6. Mounting


Caution

- Turn off the power supply to this instrument when mounting or removing it.
- Mount the DIN rail horizontally.
- This instrument fits the following DIN rails.
Top hat rail TH35 JIS C 2812-1988
- If this instrument is mounted in a position susceptible to vibration or shock, mount commercially available end plate at both ends of the instrument.
- When installing, make sure that the orientation (upper and lower) of this instrument is correct.
- When mounting or removing this instrument on the DIN rail, it must be tilted slightly.
- Secure a space of 50 mm or more in the vertical direction of the instrument, considering the wiring space of the power supply/communication line and heat dissipation.

6.1 Mounting

Mounting to the DIN rail

- Lower the lock lever of this instrument. (The lock lever of this instrument has a spring structure, but if lower it in the direction of the arrow until it stops, it will be locked in that position.)
- Hook the part ② of this instrument onto the top of the DIN rail.
- Insert the lower part of this instrument with the part ② as a fulcrum.
- Raise the lock lever of this instrument. Make sure it is fixed to the DIN rail.



Removal from the DIN rail


- Insert a flat blade screwdriver into the lock lever of this instrument and lower the lock lever until it stops.
- Remove this instrument from the DIN rail by lifting it from below.



Mounting multiple modules to the DIN rail


This section describes an example of mounting multiple modules on the DIN rail.

- Remove the line cap on the right side of the QAM1-4P.
- Lower the lock lever of the QAM1-40, and mounting the QAM1-40 to the DIN rail.
- Slide the QAM1-40 to the left and connect the connectors to each other.
- Raise the lock lever of the QAM1-40. Make sure it is fixed to the DIN rail.



Make sure the line cap is attached to the rightmost QAM1-40.

6.2 External Dimensions(Scale: mm)



7. Wiring


Warning

Turn off the power supply to this instrument before wiring.
If you work while the power is supplied, you may get an electric shock, which could result in an accident resulting in death or serious injury.

7.1 Recommended Terminal

Use a solderless terminal with an insulation sleeve in which an M3 screw fits as shown below. Use the Ring-type for the power supply and communication section.

Solderless Terminal	Manufacturer	Model	Compatible wire size	Tightening torque
Y-type	NICHIFU TERMINAL INDUSTRIES CO., LTD.	TMEX1.25Y-3	AWG22 to 16	Input/output section: 0.63 N · m Power supply section: 0.5 N · m
	J.S.TMFG.CO.,LTD.	VD1.25-B3A	AWG22 to 16	
Ring-type	NICHIFU TERMINAL INDUSTRIES CO., LTD.	TMEX1.25-3	AWG22 to 16	serial communication section: 0.3 N · m
	J.S.TMFG.CO.,LTD.	V1.25-3	AWG22 to 16	




7.2 Terminal Arrangement

7.2.1 Input and Output Terminal Arrangement

Caution

Please note that CH1, CH2 and CH3, CH4 have different terminal arrangements.



For DC current input (with an external receiving resistor), connect a receiving resistor [option 50 Ω (RES-S01-050)] between each input terminal (+ and -).
For DC current input (built-in receiving resistor), a receiving resistor (50

Ω) is not required.

7.2.2 Power Supply and Communication Terminal Arrangement


Caution

Be sure to use the correct polarity for the power supply voltage (24 V DC).

The terminal block for power supply and communication is located on the base of this instrument. Wiring by the following procedure.


(1) Case removal

- Push the release lever on the top of this instrument to unlock it.
- Remove the case.




(2) Wiring

Serial communication RS-485




CUNet communication



For CUNet communication, install a terminator [optional 100 Ω (RES-S07-100)] on the last module of the communication line.


(3) Case mounting

- Hook the case on the lower part ① of this instrument.
- Mount the case so that the lower part ① of this instrument is the fulcrum and covers the release lever. There is a clicking sound.



7.3 Using Terminal Cover Precaution

Attach the terminal cover TC-QTC (sold separately) so that the shorter one is on the right side of the case.
For the wiring of terminal numbers 11 to 20, pass through the left side of the terminal cover.



SHINKO TECHNOS CO., LTD. OVERSEAS DIVISION

Head Office: 2-5-1, Senbahigashi Minoo, Osaka Japan
URL: <https://shinko-technos.co.jp/e/> Tel: +81-72-727-6100
E-mail: overseas@shinko-technos.co.jp Fax: +81-72-727-7006