


**Shinko**

INDUSTRIAL MEASURING INSTRUMENTS



INSTRUCTION MANUAL  
FOR  
**MC SERIES**

COMMUNICATION (Options C, C5)

... Objective Models ...

MCD-130 SERIES, MCD-150 SERIES  
MCD-530 SERIES, MCD-550 SERIES  
MCR-100 SERIES, MCR-200 SERIES

This manual describes the communications of MC series (Option: C and C5).  
See each instruction manual for the operations besides the communication.

<b>1. System configuration and specifications</b>	
1.1 System configuration .....	7
1.2 Specifications .....	7
1.3 Communication interface .....	8
<b>2. Setting of the instrument .....</b>	<b>11</b>
<b>3. Communication procedure .....</b>	<b>13</b>
<b>4. Command configuration</b>	
4.1 Command configuration .....	14
4.2 Checksum calculation .....	16
<b>5. Contents of the command</b>	
5.1 Setting command	
Main setting .....	17
Temperature alarm [A1] setting .....	18
Temperature alarm [A2] setting .....	19
Proportional band [P] setting .....	20
Integral time [I] setting .....	20
Derivative time [D] setting .....	21
Anti-reset windup [ARW] setting .....	21
Heater burnout alarm setting .....	22
Manual operation output setting .....	22
Main control output proportional cycle setting .....	23
Sub control output proportional cycle setting .....	23
Sub control output proportional band setting .....	24
Main control output differential setting .....	25
Sub control output differential setting .....	25
Output high limit setting .....	26
Output low limit setting .....	26
5.2 Changing command	
Setting value Lock/Unlock designation .....	27
Auto/Manual control change .....	28
Remote/Local status change .....	29
Auto-tuning Performance/Cancellation change .....	30
5.3 Reading command	
Reading for Main setting value .....	31
Reading for Temperature alarm [A1] setting value .....	32
Reading for Temperature alarm [A2] setting value .....	33
Reading for Proportional band [P] setting value .....	34
Reading for Integral time [I] setting value .....	35
Reading for Derivative time [D] setting value .....	36

Reading for Anti-reset windup setting value .....	37
Reading for Heater burnout alarm setting value .....	38
Reading for Manual operation output setting value .....	39
Reading for Main control output proportional cycle setting value .....	40
Reading for Sub control output proportional cycle setting value .....	41
Reading for Sub control output proportional band setting value .....	42
Reading for Main control output differential setting value .....	43
Reading for Sub control output differential setting value .....	44
Reading for Output high limit setting value .....	45
Reading for Output low limit setting value .....	46
<b>5.4 Action status reading command</b>	
Reading for Setting value Lock/Unlock changing status .....	47
Reading for Auto/Manual control changing status .....	48
Reading for Remote/Local setting changing status .....	49
Reading for Auto-tuning Performance/Cancellation changing status .....	50
Reading for Control output manipulating value .....	51
Reading for Alarm output status .....	52
Reading for Input value from the sensor .....	53
<b>6. Command table</b> .....	54
<b>7. Sample program</b>	
<b>7.1 Sample program list</b> .....	56
<b>7.2 Operation methods of the sample program</b> .....	58
<b>7.3 Notice when inputting the command</b> .....	60
<b>8. When troubled</b> .....	61
<b>9. ASCII code table</b> .....	62

● MCD-130, MCD-530 series

《 Setting command 》

• Main setting .....	17
• Temperature alarm [A1] setting .....	18
• Temperature alarm [A2] setting .....	19
• Proportional band [P] setting .....	20
• Integral time [I] setting .....	20
• Derivative time [D] setting .....	21
• Anti-reset windup [ARW] setting .....	21
• Heater burnout alarm setting .....	22
• Manual operation output setting .....	22
• Main control output proportional cycle setting .....	23
• Sub control output proportional cycle setting .....	23
• Sub control output proportional band setting .....	24
• Main control output differential setting .....	25
• Sub control output differential setting .....	25
• Output high limit setting .....	26
• Output low limit setting .....	26

《 Changing command 》

• Setting value Lock/Unlock designation .....	27
• Auto/Manual control change .....	28
• Remote/Local status change .....	29
• Auto-tuning Performance/Cancellation change .....	30

《 Reading command 》

• Reading for Main setting value .....	31
• Reading for Temperature alarm [A1] setting value .....	32
• Reading for Temperature alarm [A2] setting value .....	33
• Reading for Proportional band [P] setting value .....	34
• Reading for Integral time [I] setting value .....	35
• Reading for Derivative time [D] setting value .....	36
• Reading for Anti-reset windup setting value .....	37
• Reading for Heater burnout alarm setting value .....	38
• Reading for Manual operation output setting value .....	39
• Reading for Main control output proportional cycle setting value .....	40
• Reading for Sub control output proportional cycle setting value .....	41
• Reading for Sub control output proportional band setting value .....	42
• Reading for Main control output differential setting value .....	43
• Reading for Sub control output differential setting value .....	44
• Reading for Output high limit setting value .....	45
• Reading for Output low limit setting value .....	46

《 Action status reading command 》

• Reading for Setting value Lock/Unlook changing status .....	47
• Reading for Auto/Manual control changing status .....	48
• Reading for Remote/Local setting changing status .....	49
• Reading for Auto-tuning Performance/Cancellation changing status .....	50
• Reading for Control output manipulating value .....	51
• Reading for Alarm output status .....	52
• Reading for Input value from the sensor .....	53

**● MCD-150, MCD-550 series****《 Setting command 》**

• Main setting .....	17
• Temperature alarm [A1] setting .....	18
• Proportional band [P] setting .....	20
• Integral time [I] setting .....	20
• Derivative time [D] setting .....	21
• Anti-reset windup [ARW] setting .....	21
• Manual operation output setting .....	22
• Output high limit setting .....	26
• Output low limit setting .....	26

**《 Changing command 》**

• Setting value Lock/Unlock designation .....	27
• Auto/Manual control change .....	28
• Auto-tuning Performance/Cancellation change .....	30

**《 Reading command 》**

• Reading for Main setting value .....	31
• Reading for Temperature alarm [A1] setting value .....	32
• Reading for Proportional band [P] setting value .....	34
• Reading for Integral time [I] setting value .....	35
• Reading for Derivative time [D] setting value .....	36
• Reading for Anti-reset windup setting value .....	37
• Reading for Manual operation output setting value .....	39
• Reading for Output high limit setting value .....	45
• Reading for Output low limit setting value .....	46

**《 Action status reading command 》**

• Reading for Setting value Lock/Unlock changing status .....	47
• Reading for Auto/Manual control changing status .....	48
• Reading for Auto-tuning Performance/Cancellation changing status .....	50
• Reading for Control output manipulating value .....	51
• Reading for Alarm output status .....	52
• Reading for Input value from the sensor .....	53

● MCR-100, MCR-200 series

《 Setting command 》

• Main setting .....	17
• Temperature alarm [A1] setting .....	18
• Temperature alarm [A2] setting .....	19
• Proportional band [P] setting .....	20
• Integral time [I] setting .....	20
• Derivative time [D] setting .....	21
• Anti-reset windup [ARW] setting .....	21
• Manual operation output setting .....	22
• Main control output proportional cycle setting .....	23
• Sub control output proportional cycle setting .....	23
• Sub control output proportional band setting .....	24
• Main control output differential setting .....	25
• Sub control output differential setting .....	25
• Output high limit setting .....	26
• Output low limit setting .....	26

《 Changing command 》

• Setting value Lock/Unlock designation .....	27
• Auto/Manual control change .....	28
• Auto-tuning Performance/Cancellation change .....	30

《 Reading command 》

• Reading for Main setting value .....	31
• Reading for Temperature alarm [A1] setting value .....	32
• Reading for Temperature alarm [A2] setting value .....	33
• Reading for Proportional band [P] setting value .....	34
• Reading for Integral time [I] setting value .....	35
• Reading for Derivative time [D] setting value .....	36
• Reading for Anti-reset windup setting value .....	37
• Reading for Manual operation output setting value .....	39
• Reading for Main control output proportional cycle setting value .....	40
• Reading for Sub control output proportional cycle setting value .....	41
• Reading for Sub control output proportional band setting value .....	42
• Reading for Main control output differential setting value .....	43
• Reading for Sub control output differential setting value .....	44
• Reading for Output high limit setting value .....	45
• Reading for Output low limit setting value .....	46


《 Action status reading command 》

• Reading for Setting value Lock/Unlock changing status .....	47
• Reading for Auto/Manual control changing status .....	48
• Reading for Auto-tuning Performance/Cancellation changing status .....	50
• Reading for Control output manipulating value .....	51
• Reading for Alarm output status .....	52
• Reading for Input value from the sensor .....	53




## 1. System configuration and specifications

### 1.1 System configuration

(1) RS-232C [Option code: C] Option C is not available to the MCR-100, 200 series.



(2) RS-485 Multi-drop connection [Option code: C5]



### 1.2 Specifications

Communication system	Half-duplex
Data transfer rate	2400bps (300, 600, 1200 and 4800bps) selectable by changing the pin position at the internal assembly
Synchronous system	Start-stop
Code form	ASCII
Error detection	Parity check, Checksum
Error correction	Command request repeat system
Data format	Start bit : 1 Data bit : 7 Parity bit: Even parity Stop bit : 1

Start bit	Data bit	Parity bit	Stop bit

### 1.3 Communication interface

#### (1) RS-232C (Option code: C)

Connection example between the host computer and the MCD-100 series is as follows:

- Characteristic, Based on EIA RS-232C

Connection

Signal	Abbreviation	Direction	Terminal No.
Transmit data	Tx	Output	34
Receive data	Rx	Input	35
Signal ground or Common return	COM	—	36

Cable length, maximum 10m

Adaptable connector and cable (below table or the equivalent)


Parts	Maker	Model
D sub-connector	Japan Aviation Electronics Ind. Ltd.	DB-25PFT-N
Connector cover		DB-C2-J9
Cable	Onamba Co., Ltd.	OTSC-2PVB-7/0.32TA

Connectable unit: 1


Connection method

(Host computer)

(MCD-100 series)



- In case of the MCD-500 series, the terminal numbers are as follows:  
① for Tx (Y<sub>A</sub>), ② for Rx (Y<sub>B</sub>) and ③ for COM (COM).  
Refer to the Instruction manual in detail.
- Option C is not available to the MCR series.



## (2) RS-485 (Option code: C5)

Connection example to the host computer, IF-100-C5 and the MCD-100 series is as follows:

- Characteristic, Based on EIA RS-485

Connection

Signal	Abbreviation	Direction	Terminal No.
Inverted output	Y <sub>A</sub>	Input, Output	38
Ainverted output	Y <sub>B</sub>	Input, Output	39
Signal ground or Common return	COM	—	40

Cable length, RS-232C, maximum 10m

RS-422A, maximum 1km

RS-485, maximum 1km


Adaptable connector and cable (below table or the equivalent)

Parts	Maker	Model
D sub-connector	Japan Aviation Electronics	DB-25PFT-N
Connector cover	Ind. Ltd.	DB-C2-J9
Cable	Onamba Co., Ltd.	OTSC-2PVB-7/0.32TA

Connectable units 31


Connection method [RS-232C ⇔ RS-485]

(Host computer)



(IF-100-C5) Terminator (100Ω) built-in


(MCD-100 series)




RS-232C ⇔ RS-485  
Communication converter

----- D sub (25-pin) connector

Terminator (100Ω)



## Connection method [RS-422A ⇔ RS-485]



- In case of the MCD-500 series, the terminal numbers are as follows:  
③① for Tx (Y<sub>A</sub>), ③② for Rx (Y<sub>B</sub>) and ③③ for COM (COM).
- In case of the MCR-100, 200 series, the terminal numbers are as follows:  
⑯ for Y<sub>A</sub>, ⑯ for Y<sub>B</sub> and ⑯ for COM.

Refer to each Instruction manual in detail.

- As for the shielding wire
  - Connect the shielding wire **only one side** to FG or ground terminal so as not to flow the current into the shielding wire.
  - The FG or ground terminal must be grounded.
  - If both sides of the wire are connected to the FG or ground terminal, the circuit is made between the wire and ground, and the **noise may easily occur by the current**.
- As for the terminator (terminal resistor)
  - The more the communication line becomes long, sometimes, the less communication performs since the transfer waveform becomes wrong owing to the echo. To prevent this, connect the terminator.
  - The place to connect should be the physical terminal of the communication cable.
  - Our made Communication converter [IF-100-C5] is to be provided on separately sold.