# **ISOLATOR** (with indication function)

Model: SAV

#### ■ Model

Power supply
0: 100 to 240V AC
1: 24V AC/DC

#### ■ How to order

Specify a model. (e.g.) SAV-0

Default value

Input	1 to 5V DC	
Output	4 to 20mA DC	

## **■** Input specifications

DC voltage

Input range	Input	Allowable signal	
input range	resistance	source resistance	
0 to 10mV DC		$20\Omega$ or less	
-10 to 10mV DC		$40\Omega$ or less	
0 to 50mV DC	]		
0 to 60mV DC		200 $\Omega$ or less	
0 to 100mV DC	1ΜΩ		
0 to 1V DC		$2k\Omega$ or less	
0 to 5V DC			
1 to 5V DC		1k $\Omega$ or less	
0 to 10V DC			

## ■ Output specifications Output 1 (Universal)


When the output range lower limit is zero, (even if zero adjustment results in a negative value), the output value will not be negative.

#### DC current

	Allowable	Zero	Span
Output range	load	adjustment	adjustment
	resistance	range	range
4 to 20mA DC	$700\Omega$ or less	-5 to 5%	95 to 105%
0 to 20mA DC	$700\Omega$ or less	0 to 5%	95 to 105%
0 to 12mA DC	1.2kΩ or less	0 to 5%	95 to 105%
0 to 10mA DC			95 to 105%
1 to 5mA DC	2.4kΩ or less	-5 to 5%	95 to 105%

## DC voltage

	Allowable	Zero	Span
Output range	load	adjustment	adjustment
	resistance	range	range
0 to 1V DC	100 $\Omega$ or more	0 to 5%	95 to 105%
0 to 5V DC	500Ω or more	0 to 5%	95 to 105%
1 to 5V DC	500Ω or more	-5 to 5%	95 to 105%
0 to 10V DC	1k $Ω$ or more	0 to 5%	95 to 105%



### **■** Performance

Accuracy:

Input : Within ±0.1%
Output : Within ±0.1%
Display accuracy:

Within input accuracy ±1 digit

Response time: 0.5 sec. (typical) (0  $\rightarrow$  90%)

Temperature coefficient: ±0.015%/℃

Insulation resistance:  $10M\Omega$  or more, at 500V DC (Input - Output - Power)

Dielectric strength: 2.0kV AC for 1 minute
(Input - Output - Power)

#### **■** General structure

Case : Flame-resistant resin Color: Light gray


Front panel: Membrane sheet
Setting : By the front keypad
Indication : Input display:

7-segment, Red LED display 4-digit Character size, 7.4 x 4.0mm (H x W)

Output display:

7-segment, Green LED display 4-digit Character size, 7.4 x 4.0mm (H x W)

Power indicator: Green LED





## ■ Installation specifications

Power supply : 100 to 240V AC 50/60Hz

24V AC/DC 50/60Hz

Allowable voltage range: 85 to 264V AC

20 to 28V AC/DC

Power consumption : Approx. 6VA Ambient temperature : -5 to  $55^{\circ}$ C

Ambient humidity : 35 to 85%RH (non-condensing)

Weight : Approx. 120g Mounting : DIN rail mounting

External dimensions : 22.5 (W) x 75 (H) x 100 (D)mm

#### ■ Attached functions

Power failure countermeasure:

The data is backed up in non-volatile IC memory.

Self diagnosis:

The CPU is monitored by a watchdog timer, and when an abnormal status is found on the CPU, the unit is switched to warm-up status turning all outputs off.

## ■ Environmental specification

RoHS directive compliance

## ■ Settings

Function keys

(1) UP Key : Increases the numeric value.
(2) DOWN Key : Decreases the numeric value.
(3) MODE Key : Selects the setting mode.
(4) SUB MODE Key: Press with the MODE Key to select the setting mode.

#### Setting items

Set by pressing the MODE Key for 3 seconds

(1) Output zero adjustment(2) Output span adjustment

Set by the MODE Key and SUB MODE Key

- (1) Set value lock
- (2) Input range
- (3) Decimal point place
- (4) Output 0% value
- (5) Output 100% value
- (6) Filter time constant
- (7) Sensor correction
- (8) Output type/range
- (9) Output Normal/Reverse
- (10) Display selection
- (11) Indication time

## Displays and indicators

Input display : Indicates the input value.

Indication of -2000 or less:

The minus (-) sign and input value

light alternately.

Indication of 10000 or more: The lower 4 digits flash.

Under range: "2 2 2 2 " flashes on the Input display. Over range: " " flashes on the Input display.

Warm-up indication:

For approx. 3 seconds after the power to the instrument is turned on, the input type is indicated on the Input display, and the Output type is indicated on the

Output display.

Output display : Indicates the output volume in

percentage (%) form.

Power indicator: The green LED lights when the power

to the instrument is turned on.

#### ■ Ferrules

Terminals from 1 to 4

Insulation sleeve attached (Phoenix Contact GMBH & CO.)

Crimping pliers (Phoenix Contact GMBH & CO.)

CRIMPFOX ZA3 CRIMPFOX UD6

#### Terminals from 5 to 9


Insulation sleeve attached (Phoenix Contact GMBH & CO.)

Al0.25-8YE 0.2 – 0.25mm<sup>2</sup> Al0.34-8TQ 0.25 – 0.34mm<sup>2</sup> Al0.5-8WH 0.34 – 0.5mm<sup>2</sup>

Crimping pliers (Phoenix Contact GMBH & CO.)

CRIMPFOX ZA3 CRIMPFOX UD6

# ■ Circuit configuration, terminal arrangement



## ■ External dimensions (Scale: mm)

