
## SE series SPEC. SHEET

# **Isolator** (with indication function)

Model: SE2V



0: 100 to 240V AC 1: 24V AC/DC

#### ■ How to order

Specify the model (e.g.) SE2V-1-0

#### Default value

CH1 input	1 to 5V DC
CH2 input	1 to 5V DC
CH1 output	4 to 20mA DC
CH2 output	4 to 20mA DC

## ■ Accessories (sold separately)

Communication cable for the console software: CMB-001

## ■ Input specification

DC voltage


Input	Input resistance	Allowable signal source resistance					
0 to 10mV DC		$20\Omega$ or less					
-10 to 10mV DC	1МΩ	$40\Omega$ or less					
0 to 50mV DC							
0 to 60mV DC		200 $\Omega$ or less					
0 to 100mV DC							
0 to 1V DC		2kΩ or less					
0 to 5V DC		_					
1 to 5V DC		1k $\Omega$ or less					
0 to 10V DC							

## ■ Output specification

When the output range lower limit is zero, (even if zero adjustment results in a negative value), the output value will not be negative.

#### DC current

C current						
	Output range	Allowable load resistance	Zero adjustment range	Span adjustment range		
	4 to 20mA DC	$700\Omega$ or less	-5 to 5%	95 to 105%		
	0 to 20mA DC	$700\Omega$ or less	0 to 5%	95 to 105%		
	0 to 12mA DC	1.2kΩ or less	0 to 5%	95 to 105%		
	0 to10mA DC	1.2kΩ or less	0 to 5%	95 to 105%		
	1 to 5mA DC	2.4kΩ or less	-5 to 5%	95 to 105%		



## DC voltage

Output range	Allowable load resistance	Zero adjustment range	Span adjustment range
0 to 1V DC	100 $\Omega$ or more	0 to 5%	95 to 105%
0 to 5V DC	$500\Omega$ or more	0 to 5%	95 to 105%
1 to 5V DC	$500\Omega$ or more	-5 to 5%	95 to 105%
0 to 10V DC	1k $\Omega$ or more	0 to 5%	95 to 105%

## ■ Performance

Accuracy (When ambient temperature is 23°C):

Input: Within ±0.1% Output: Within ±0.1%

Indication accuracy: Within input accuracy  $\pm 1$  digit

Input sampling period: 25ms, 125ms, 250ms (Selectable by keypad) Response time: 65ms (typ.) (0—90%) (Input sampling period 25ms)

225ms (typ.)  $(0\rightarrow90\%)$  (Input sampling period 125ms) 425ms (typ.)  $(0\rightarrow90\%)$  (Input sampling period 250ms)

(Selectable by keypad Temperature coefficient: ±0.015%/°C or less

Insulation resistance:  $10M\Omega$  or more, at 500V DC (Input – Output – Power supply)

Dielectric strength: 2.0kV AC for 1 minute

(Input – Output – Power supply)



#### **■** General structure

Case: Flame-resistant resin, Color: Light gray

Front panel: Membrane sheet Setting: By the front keypad


Connector for console software: Only for CMB-001

Indication: Input display: 7-segment, Red LED display 4-digit Character size 10×4.6mm (H×W)

Output display: 7-segment, Red LED display 4-digit

Character size 10×4.6mm (H×W)

Power indicator: Green LED CH1 indicator: Yellow LED CH2 Indicator: Yellow LED



## ■ Installation specifications

Power supply: 100 to 240V AC 50/60Hz, 24V AC/DC 50/60Hz Allowable voltage range: 85 to 264V AC, 20 to 28V AC/DC

Power consumption: Approx. 8VA Ambient temperature: -5 to 55°C

Ambient humidity: 35 to 85%RH (Non-condensing)

Mounting: DIN rail mounting

External dimensions: W30×H88×D108mm (including the socket)

Weight: Approx. 190g (including the socket)

## ■ Attached functions

Auto-light function: Display brightness is controlled in accordance with the surrounding area. Unnecessary brightness is reduced, saving energy.

Power failure countermeasure: The data is backed up in nonvolatile IC memory.

Self diagnosis: The CPU is monitored by a watchdog timer, and when an abnormal status is found on the CPU, the unit is switched to warm-up status with tuning all outputs off.

## Environmental specification

RoHS directive compliance

#### Settings

Function keys

- (1) UP Key: Increases the numeric value.
- (2) DOWN Key: Decrease the numeric value.
- (3) MODE Key: Selects the setting mode.
- (4) SUB-MODE Key: Turns the displays ON again when they are in OFF status.

(The UP, DOWN or MODE Key also turns the displays ON again when they are in OFF status.)  $\,$ 

## Displays and indicators

Input display: Indicates the input value

Indication of -2000 or less (for DC input):

The minus (-) sign and input value light alternately. Indication of 10000 or more:

Indication of 10000 or more: The lower 4 digits flash.

Under range: "\_\_\_\_ " flashes on the input display.

Over range: " " flashes on the input display

" flashes on the input display

" flashes on the input display

Warm-up indication: For approx. 3sec. after the power to the instrument is turned on, the input type of CH1 is indicated on the input display, the input


is indicated on the input display, the input type of CH2 is indicated on the output display.

Output display: Indicates output volume in percentage (%) form. Power indicator: The green LED lights when the power to the instrument is turned on.

CH1 indicator: The yellow LED lights when CH1 is selected during Display selection mode.


CH2 indicator: The yellow LED lights when CH2 is selected during Display selection mode.

#### ■ Solderless terminal





## ■ Circuit configuration and terminal arrangement



## ■ External dimensions (Scale: mm)

