

PCD-33A


User focused functionality





Max 9-patterns, 9-steps each, programmable Simple time and temperature setting





Multi-point program control, using the set value digital transmission





Max. 9 patterns

9 steps per pattern are available for program control.

Easy programming

To set the program, just input the step temperature and step time for each step.


Multi-input

18 types of input are provided from thermocouple (10 types), RTD (2 types), DC current (2 types) and DC voltage (4 types).

Drip-proof structure

IP66 for the front face

Model



Designate your specifications in the \square , $\square\square\square$ columns.


- When adding an option, enter it punctuated by a comma.


 (*1) For the power supply, 100 to 240V AC is standard. However, when ordering 24V AC/DC, enter "1" after the input.

 (*2) When [C5 option] or [SVTC option] is added, the external operation function is not usable. [C5 option] and [SVTC option] cannot be added together.

 (*3) When [P24 option] is added, Alarm 2 (A2) is not usable.

Example of order code





Time →

Enhanced communication functions

The communication type can be selected from 5 types (Shinko protocol, Set value digital transmission, Set value digital reception, Modbus ASCII mode and Modbus RTU mode). If Set value digital transmission is selected, SV of PCD-33A can be transmitted digitally to the JC \square -33A series, etc. to which communication function (C5 option) is added. If Set value digital reception function is selected, PCD-33A can also receive the set value digitally from devices such as the JC -33A series, etc. to which communication function (C5 option) is added.

Rated scale

Input type		Input range	
·	K	-200 to 1370 °C	−320 to 2500 °F
		—199.9 to 400.0℃	-199.9 to 750.0 °F
	J	-200 to 1000 °C	−320 to 1800 °F
	R	0 to 1760 ℃	0 to 3200 °F
	S	0 to 1760 ℃	0 to 3200 °F
Thermocouple	В	0 to 1820 ℃	0 to 3300 °F
	E	-200 to 800 °C	−320 to 1500 °F
	T	—199.9 to 400.0°C	-199.9 to 750.0 °F
	N	-200 to 1300 °C	−320 to 2300 °F
	PL-II	0 to 1390 ℃	0 to 2500 °F
	C(W/Re5-26)	0 to 2315 °C	0 to 4200 °F
	Pt100	—199.9 to 850.0°C	-199.9 to 999.9 °F
RTD		—200 to 850 °C	−300 to 1500 °F
NID	JPt100	—199.9 to 500.0°C	-199.9 to 900.0 °F
		—200 to 500 °C	─300 to 900 °F
DC current	4 to 20mA	—1999 to 9999 (*)	
DO Current	0 to 20mA	—1999 to 9999 (*)	
	0 to 1V	—1999 to 9999(*)	
DC voltage	0 to 5V	—1999 to 9999 (*)	
	1 to 5V	—1999 to 9999 (*)	
	0 to 10V	—1999 to 9999(*)	

- (*) For DC current and DC voltage input, scaling and decimal point place change are possible.
 - -1999 to 9999, -199.9 to 999.9, -19.99 to 99.99, -1.999 to 9.999 For DC current input, 50Ω shunt resistor (sold separately) has to be externally installed.

Standard specifications

Display	PV Red 4-digit character size: 18.0 x 8.0mm (H x W) SV Green 4-digit character size: 12.6 x 6.0mm (H x W) STEP Green 1-digit character size: 12.6 x 6.0mm (H x W)		
Input	ThermocoupleK, J, R, S, B, E, T, N, PL-II, C (W/Re5-26) External resistance: 100 Ω or less (For B input: 40 Ω or less) RTD		
Accuracy (setting, indication)	Thermocouple		
Time indication accuracy	Within $\pm 0.5\%$ of setting time		
Input sampling period	0.25 seconds Relay contact 1a1b 3A 250V AC(resistive load), 1A 250V AC (inductive load $\cos \phi = 0.4$), Electric life: 100,000 cycles		
Control output (OUT)			
Control action	Control action type PID action (with auto-tuning) PI action (when derivative time is set to 0) Paction (when both derivative and integral times are set to 0) ON/OFF action (when proportional band is set to 0) Control parameter Proportional band (P) Thermocouple, RTD (without decimal point): 0 to 1000°C (0 to 2000°F) Thermocouple, RTD (with decimal point): 0.0 to 999.9°C (°F) For DC input, 0.0 to 100.0% Integral time(I)		

	A1 and A2 alarm types and status Energ	gized/Deenergized can be selected by keypad operation.			
	All alarm actions (except for Process high alarm and low alarm) are ±deviation setting from SV. If Energized is selected and when				
	input is out of the range, the alarm output turns ON (If Deenergized is selected, the alarm output turns OFF).				
	Alarm type	Setting range			
	No alarm action High limit alarm	—Input span to input span (Off when set to 0 or 0.0) (Deviation setting)			
	Low limit alarm	—Input span to input span (Off when set to 0 or 0.0) (Deviation setting)			
	High/Low limits alarm	0 to input span (Off when set to 0 or 0.0) (Deviation setting)			
	High/Low limit range alarm	0 to input span (Off when set to 0 or 0.0) (Deviation setting)			
	Process high alarm	Input range minimum value to input range maximum value			
Alarm 1 (A1)	Process low alarm	Input range minimum value to input range maximum value			
Alarm 2 (A2)	High limit alarm with standby	—Input span to input span (Off when set to 0 or 0.0) (Deviation setting)			
, ,	Low limit alarm with standby	—Input span to input span (Off when set to 0 or 0.0) (Deviation setting)			
	High/Low limits alarm with standby	0 to input span (Off when set to 0 or 0.0) (Deviation setting) negative minimum value is —199.9 and the positive maximum value is 999.9.			
		e as scaling span, and input range minimum (or maximum) value is the same as the scaling low			
	(or high) limit value.	, as southing spain, and impartatings minimum (or maximum) value is the same as the southing low			
	Setting accuracy The same as the indi	ication accuracy			
	Action				
		3A 250V AC (resistive load), 1A 250V AC (inductive load $\cos \phi = 0.4$), Electric life: 100,000 cycles			
		uts (Time signal output, Pattern end output and RUN output) by front keypad operation.			
	Time signal output: If time signal OFF time and time signal ON time are set, time signal is outputted within the total time taken for				
Event output (EVT)	1 pattern during program control.				
Event output (EV1)	Pattern end output: Outputs signal for the RUN output: Outputs during products				
	RUN output : Outputs during program control. Output : Relay contact, 1a 3A 250V AC (resistive load), 1A 250V AC (inductive load cos ϕ =0.4), Electric life: 100,000 cycles				
		oltage fluctuation range: 85 to 264V AC), 24V AC/DC 50/60Hz(Allowable voltage fluctuation			
Supply voltage	range: 20 to 28V AC/DC)	onage nationality range. 33 to 2044 NOJ, 244 NO/BO 30/00112/ illowable voltage nationality			
Power consumption	Approx. 8VA				
	If control output (OUT) is non-contact voltage output or DC current output, insulation tests must not be carried out between control				
Insulation resistance	output (OUT) terminal and external operation terminal, and between control output (OUT) terminal and communication terminal				
	because they are not insulated from one another. Other combinations except the above: $10M\Omega$ or more, at 500V DC				
	·	ninal, between input terminal and power terminal 1.5kV AC for 1 minute			
Dielectric strength	Between power terminal and ground ter	minal 1.5kV AC for 1 minute			
	Between output terminal and ground terminal, between output terminal and power terminal 1.5kV AC for 1 minute				
Environment	Ambient temperature: 0 to 50°C (32 to 122°F), Ambient humidity: 35 to 85%RH (non-condensing)				
Safety standard	UL: Power input rating 100-240V AC, 24	4V AC/DC File No. E159038			
Material, Color	Material: Flame-resistant resin, Color: L	ight gray			
Mounting method	Flush, Mounting brackets: Screw type	Mountable panel thickness: 1 to 8mm			
Dust-proof/Drip-proof	IP66 for front face				
Setting method	Sheet key input				
Weight	Approx. 370g				
Attached function	Power failure countermeasures, Self dia	agnosis, Automatic cold junction temperature compensation (only for thermocouple), Sensor			
Attached function	burnout alarm, Input burnout				

■Program performance

Number of patterns	9 patterns	
Number of steps	9 steps/pattern	
External operation function	Program control can start/stop by opening/closing the external contact or open collector. Program control starts when the contact is switching from Open to Closed, and stops when the contact is switching from Closed to Open.	
WAIT function	During program run, the program does not proceed to the next step until deviation between PV and SV when step ends enters the WAIT set value. Setting range Thermocouple, RTD (without decimal point): ±(0 to 100)°C(°F) Thermocouple, RTD (with decimal point): ±(0.0 to 100.0)°C(°F) DC input: 0 to 1000 (The placement of the decimal point follows the selection.)	
HOLD function	Program control RUN time is held temporarily.	
ADVANCE function	The step during program control RUN can be stopped and advanced to the next step.	
Other functions	Step time unit selection (Hour:Minute or Minute:Second), Program control start type selection (PV start or SV start), Step temperature setting when starting program control	
Program time range	0 to 99 hours 59 minutes/step, or 0 to 99 minutes 59 seconds/step	
Time setting accuracy	Within ±0.5% of setting time	
Setting resolution	Temperature: 1°C(1°F) or 0.1°C(0.1°F), Time: 1 minute or 1 second	
Status after power is restored	Program starts to perform from the status before power failure. (Time error after power is restored: Max. 1 minute)	

Options

Serial communication [C5]	Each setting status change, set value reading and setting, etc. of PCD-33A can be operated from the external computer. (If C5 option is added, external operation function is not usable. The SVTC option and external operation function cannot be applied together.) Communication interface	
Insulated power output [P24]	Outputs 24V DC. This is used for the power of 2-wire transmitter such as a pressure transducer. (If the P24 option is applied, Alarm 2 (A2) is not usable.) Output voltage	

Set value digital transmission (Master)

If Set value digital transmission (Master) is selected during Communication protocol selection, SV of PCD-33A can be

transmitted digitally to the controllers such as JC -33A series (Slave) with communication function (C5 option).

Set value digital reception (Slave)

If Set value digital reception (Slave) is selected during Communication protocol selection, the SV can be received from the PC-900 series/PCD-33A (Master) with Set value digital transmission (SVTC option).

(If the SVTC option is added, external operation function is not usable, and C5 option and external operation function cannot be

applied together.)

Terminal cover [TC] Color Black [BK]


Set value digital

transmission [SVTC]


Electric shock protection terminal cover Be sure to use this terminal cover by adding this option if operator may touch the back of the controller while running the controller.

Case: Black, Panel: Dark gray

External dimensions (Scale: mm)



Panel cutout (Scale: mm)






Caution: If lateral close mounting is used, IP66 specification (Dust-proof/Drip-proof) may be compromised, and all warranties will be invalidated.



· Panel thickness is 1 to 8mm.

As the case is made of resin, do not use excessive force while screwing in the mounting bracket. The case or screw type mounting bracket could be damaged. The torque should be 0.12N m.

Terminal arrangement



• POWER SUPPLY: 100 to 240V AC or 24V AC/DC

· OUT : Control output • A1 : Alarm output 1 · A2 : Alarm output 2

• P24 : Insulated power output (P24 option) · RS-485 : Serial communication (C5 option)

• EVT : Event output

· EXT CON INPUT : External operation input • TC : Thermocouple input


· RTD : RTD input


·DC : DC current, DC voltage inputs

- The terminal block is designed to be wired from the left side.
- Dotted lines show options.
- When [P24 option] is added, Alarm 2 (A2) is not usable.
- · When [C5 option] is added, external operation function is not usable.

Solderless terminal

Use a solderless terminal with an insulation sleeve in which the M3 screw fits as shown below. The torque should be 0.63N m.







- To ensure safe and correct use, thoroughly read and understand the manual before using this instrument
- This instrument is intended to be used for industrial machinery, machine tools and measuring equipment. Verify correct usage after consulting purpose of use with our agency or main office.
- (Never use this instrument for medical purposes with which human lives are involved.)

 External protection devices such as protection equipment against excessive temperature rise, etc. must be installed, as malfunction of this product could result in serious damage to the system or injury to personnel. Also proper periodic maintenance is required.
- This instrument must be used under the conditions and environment described in the manual. Shinko Technos Co., Ltd. does not accept liability for any injury, loss of life or damage occurring due to the instrument being used under conditions not otherwise stated in the manual.

Caution with respect to Export Trade Control Ordinance

To avoid this instrument from being used as a component in, or as being utilized in the manufacture of weapons of mass destruction (i.e. military applications, military equipment, etc.), please investigate the end users and the final use of this instrument, In the case of resale, ensure that this instrument is not illegally exported.

·This catalog is as of January 2009 and its contents are subject to change without notice. If you have any inquiries, please consult us or our agency.

SHINKO TECHNOS CO., LTD. **OVERSEAS DIVISION**

Reg. Office: 2-5-1, Senbahigashi, Minoo, Osaka, 562-0035, Japan

Tel : 81 - 72 - 727 - 6100 Fax : 81 - 72 - 727 - 7006

URL : http://www.shinko-technos.co.jp : overseas @ shinko-technos. co. jp E-mail